Xerox® WorkCentre® 3655 **Quick Tips**



ESDC

For Service and Supplies: NSD.prv or 1-855-818-4908









Press the Services Home button




Copy

- Select required features
- Enter copy quantity

How to Release a Secure Print Job

- 1. From the printer, press the [Job Status] button on the Control Panel. The Job Status screen will be displayed.
- 2. Select the [Secure Print Jobs & More] tab on the Touch Screen.
- 3. Select the [Secure Print] button.
- 4. Select the job, and then select the **[Document List]** button.
- 5. When prompted, enter your password and then select the [Confirm] button.
- 6. Select your job, select the **[Print]** button, and respond to any on-screen prompts.
- 7. Select the **[Close]** button several times until the Job Status screen is displayed.
- 8. Press the [All Services] button on the Control Panel to exit.



Fax


- Select Enter Number field
- Enter the fax number using the numeric keypad
- Confirm the number by pressing the Add button
- If additional numbers are required, repeat steps above
- Select required features





Press Start





Email

- Select email feature and enter username and password
- Select New Recipient
- Select To, CC, or BCC
- Using the keyboard, enter the email address
- Select Add to add the address to the recipient list
- If additional addresses are required, repeat steps above
- Select Save

For more information, please refer to:

NSD.prv

